



Fitting Guide Prokraft AMC Premium Magnifier Kit

To complete this kit we recommend:

L4BSH – Bushing set (the interstitial bushing in this set is not required for basic kit completion)

L4DRL – 9.7mm drill

Blank – 57mm minimum

1] Drill your blank using a 9.7mm drill, abrade the brass pen tube to assist with adhesion and glue the brass tube into your blank

2] Turn and finish the blank on your lathe as required

3] To assemble the kit it is necessary to unscrew the head connector from the head – ensure you **DO NOT DROP THE GLASS OR SURROUND**

4] Using your preferred method press the finial and head connector onto the finished tube/blank part using a suitable lathe/vice/press

5] Screw the magnifier and surround back onto the head connector ensuring the glass is fitted inside the small groove in the glass surround

6] Your magnifier is now complete and ready to use

ADDENDUM:

The AMC magnifier kit uses the same tube diameter as the Rossetti pen kit and the Let4 letter opener kit and there are chrome rings available separately that can be added to the kits for a more complex and interesting kit – The guide for fitting these can be found in the Let4 fitting guide or the Rossetti fitting guide

Optional extras for this kit: ROSRING – chrome interstitial rings

The AMC, Rossetti Pen and LET4 kits make a fabulous matching set when completed together